


How to measure Hose lengths

The lengths of assemblies are determined by measuring from face centerline to face centerline of angular fittings, and to the end of face surface to end of face surface for straights. The diagrams, shown below, are examples of how to measure hose assemblies precisely.



How To Measure Fitting Angle

To measure the angular rotation of hose fittings, place the fitting nearest you at position 0° (see illustration at right). Measure counter-clockwise to the desired position of the rear fitting. If the angle between fittings desired is position 0° to position 0° , specify 000. For example, this illustration shows a 270° angle.

